


B53, F53, FT53



Pos Ref Ref No.	Detaljnr. Part nr. Teilnr Pièce no	Benämning	Description	Bezeichnung	Désignation	Antal Quant Anz Quant	Anmärkning Remark Bemärkung Remarque
1	150019	Lagerdistansring	Spacer	Lagerabstandsring	Anneau distance pailer	4	
2	163240	Hävarm, vänster	Lever, left	Hebelarm, links	Bras, gauche	1	
3	163241	Hävarm, höger	Lever, right	Hebelarm, rechts	Bras, droit	1	B,F,FT,53
4	947015	Planbricka	Washer	Scheibe	Rondelle	14	B,F,FT,53
5	946004	Mutter	Nut	Mutter	Ecrou	3	
6	132204	Häft huvud	Stapling head	Heftkopf	Tête d'agrafge	1	B,F,FT,53
7	946516	Skruv	Screw	Schraube	Vis	4	B,F,FT,53
9	150018	Lagerdistansring	Spacer	Lagersbstandsring	Anneau distance pailer	2	B,F,FT,53
10	134124	Länk för häft huvud	Stapling head link	Häftkopf-Gelenk	Articulation de tête	2	B,F,FT,53
11	946561	Skruv	Screw	Schraube	Vis	4	
12	946646	Skruv	Screws	Schraube	Vis	1	
13	163223	Bakre länk	Rear link	Hinterer Gelenk	Articulation arrière	2	
14	150206	Distanshylsa	Spacer	Abstandbüchse	Douille de distance	1	
16	173017	Dragfjäder	Spring	Zugfeder	Ressort de tension	1	
17	146182	Mutter	Nut	Mutter	Ecrou	1	
18	150225	Bussning	Bushing	Büchse	Douille	2	
19	975003	Tallriksfjäder	Cup spring	Tellerfeder	Ressort assiette	2	
20	156767	Konsol	Bracket	Konsole	Console	2	B,F,FT,53
21	158146	Häftstad	Anvil	Rillplatte	Enclure	2	B2, F2,53
22	946524	Skruv	Screw	Schraube	Vis	2	
23	150307	Lagerdistans	Spacer	Lagerabstandsring	Anneau distance palier	2	
24	158007	Häfttunga	Anvil tongue	Abosszunge	Langue enclure	1	FT,53
25	946558	Skruv	Screw	Schraube	Vis	5	
26	163292	Främre länk	Front link	Vorderes Gelenk	Articulation d'avant	2	
28	146183	Axel skruv	Pin screw	Schraubachse	Vis-arbre	1	
29	163290	Tryckstång	Push rod	Stossgelenk	Barre pression	1	
33	156699	Fjäderhänge	Spring holder	Federhalter	Attachement ressort	1	
34	153051	Bakre fot	Rear foot	Hinterer Fuss	Pied arrière	1	
37	149063	Pedalplatta	Pedal cover	Fusshebelabdeckung	Couverture pédale	1	
40	165094	Sidoställd pedal	Treadle	Fusshebel	Pédale	1	
41	157066	Stöd	Support	Stütze	Support	1	
44	149064	Dämpare	Bumper	Dämpfer	Amortisseur	1	
45	156615	Fjäderhållare	Spring holder	Federhalter	Appui ressort	1	B
	156616	Fjäderhållare	Spring holder	Federhalter	Appui ressort	1	F,FT
46	174050	Yttre stoppfjäder	Outer stop spring	Äussere Haltfeder	Retardation extérieure	1	B
	174049	Yttre stoppfjäder	Outer stop spring	Äussere Haltfeder	Retardation extérieure	1	F,FT
47	174047	Inre stoppfjäder	Inner stop spring	Innere Haltefeder	Retardation intérieure	1	B
	174048	Inre stoppfjäder	Inner stop spring	Innere Haltefeder	Retardation intérieure	1	F,FT
48	945055	Spännstift	Spring pin	Spannstift	Goupille	1	
49	951001	Axelsäkring	Clip	Achsenicherung	Fixation arbre	4	B,F,FT,53
50	947014	Bricka	Washer	Scheibe	Rondelle	2	B,F,FT,53
51	946543	Skruv	Screw	Schraube	Vis	2	FT
61	946668	Skruv	Screw	Schraube	Vis	2	
62	946707	Skruv	Screw	Schraube	Vis	1	
63	149092	Nylonplug	Plug	Nylonstopfen	Bouchon	1	